

ASSEMBLY INSTRUCTION
1118-MC1863DT-2426



A	B	C	D	E	F
1 PC	2 PCS	1 PC	14 PCS	1 PC	1 PC




FIG. 1











FIG. 2



A	B	C	D	E	F
			 M8*20	 P5	 P4
1 PC	2 PCS	1 PC	14PCS	1 PC	1 PC




FIG.
3












FIG.
4


ADJUSTMENT



A	B	C	D	E	F
					
1 PC	2 PCS	1 PC	14 PCS	1 PC	1 PC



**FIG.
5**



**FIG.
6**

